

The Barre

Ballet Barre Care & Maintenance Sheet.



CARE AND MAINTENANCE INSTRUCTIONS FOR YOUR BALLET BARRES

Maintenance instructions must be followed to ensure the longevity and aesthetics of your Ballet Barres.

The Classic Range Ash wood Ballet Barres are supplied sanded and smooth to the touch, untreated with a natural finish. Over time the Ash wood Barre will acquire a natural patina from oils in the hand.

Here at The Barre we do not recommend treating your Ash ballet Barres with synthetic oils and varnishes. This may hinder the cleaning and longevity of the Barre.

Maintenance after use.

Apply antibacterial cleaner to a clean cloth and wipe the Barres and brackets. Do not use sprays or chemical wipes directly on the Barre as it may cause discolouration to the Ash wood. Then wipe over with a clean dry cloth.

Blemishes and marks may be removed from wooden Barres by lightly sanding with very fine sandpaper. Marks on the brackets can be removed using a mild cleaning solution with a damp cloth.

Industrial or abrasive cleaners should be avoided as they may damage the surface of the Barre and or brackets.

Just A Note.

Please remember a Ballet Barre is an Aid To Balance Only and should never be used for anything other than its designed purpose.

We strongly recommend you use a qualified trade's person for any installations needed.